

**Purdue University**  
**School of Nuclear Engineering**  
**NUCL 355 - Nuclear Thermal-Hydraulics Laboratory**

Prelab 4: Flow Around Bodies

1. A vortex flow meter is a device that measures flow rate by determining the vortex shedding rate from an obstacle in the flow path. Assume you have a pipe 10 cm in diameter with a rod inserted across the pipe perpendicularly to the flow direction. The rod is 5 mm in diameter. Water at 20°C flows through the pipe. The vortex shedding frequency is measured to be  $126 \text{ s}^{-1}$ .
  - a. What is the volumetric flow rate?
  - b. What is the minimum flow rate for which your calculation method would be valid?
2. Explain how hydrogen bubbles will be produced in this experiment.